

# Purge the scrap bins

## \* Woodshop\*

In the woodshop free bin and the free board caddy in the lathe area, remove any wood that:

- Is painted or treated
- Has nails/metal inside
- Is heavily splintered
- Is "swiss-cheesed" with little material to use, etc.

## \*Metalshop\*

In the metalshop materials bins in the powdercoating area, transfer any unsuitable metals from the suitable bin to the unsuitable bin. Unsuitable metals includes anything:

- Galvanized/coated
- Swiss-cheesed
- Any materials that aren't identifiable as aluminum or carbon steel

## \*Studio\*

In the two scrap bins by the laser cutters:

- remove any small/unusable pieces
- remove any pieces not on the allowed materials list (see QR code posted on the top of laser 2)
- break down any pieces with large voids so they fit nicely within the bins

---

Revision #1

Created 2 June 2025 14:50:54 by Bookstack Admin

Updated 14 June 2025 15:10:55 by Bookstack Admin