

Dye Sublimation Printer

- Check ink levels on dye sub printer

Check ink levels on dye sub printer

Prolonged use of the product when the ink level is below the line on the tank could damage the printer.

* Verify on the front of the machine that the ink tank levels are not below the minimum marking. If they are, file a tool report.

- Tool report: <https://airtable.com/appbllORlmbIxNU1L/shrluff2WSzy8c3xd>