

Lawnmower

- Clean Lawnmower

Clean Lawnmower

- * Remove the battery
- * Clean the undercarriage using a putty knife and wire brush
- * Reattach the battery