

Check and Refill Quench Bucket

Check the water level in the quench bucket. If the water level is an inch or more below the top line, refill the quench bucket to the top line with tap water.

Remove any scrap metal at the bottom of the quench bucket, and move to the scrap bucket.

Revision #2

Created 1 August 2026 16:44:38 by Bookstack Admin

Updated 1 August 2026 16:49:11 by Bookstack Admin