Check and Refill Quench Bucket

Check the water level in the quench bucket. If the water level is an inch or more below the top line, refill the qunch bucket to the top line with tap water.

Remove any scrap metal at the bottom of the quench bucket, and move to the scrap bucket.

Revision #2
Created 2026-08-01 16:44:38 UTC by Bookstack Admin
Updated 2026-08-01 16:49:11 UTC by Bookstack Admin