

Check Consumables

- Check if the tip is in good condition: no obvious damage, good point, no deep pitting. Replace tip if needed.
- Check the sponge to make sure it is in good condition. Replace sponge if needed.

Revision #1

Created 10 January 2025 15:12:54 by Paul Mazaitis

Updated 22 March 2025 17:05:39 by Paul Mazaitis