

Clean Lawnmower

- * Remove the battery
 - * Clean the undercarriage using a putty knife and wire brush
 - * Reattach the battery
-

Revision #1

Created 2 June 2025 14:40:57 by Bookstack Admin

Updated 14 June 2025 15:10:55 by Bookstack Admin