Clean Miter Saw

Service manual: https://drive.google.com/file/d/16HFrtwBzy-s0uS8aojnePJ2yyeupkZX2/view?usp=drive_link

Procedure

Unplug before cleaning.

The miter saw should be cleaned with vacuum or a dry rag as needed to keep free of dust. Yellow plastic panel on work surface should be removed if there is saw dust build or debris up underneath.

Check the sliding rails, if there is resistance, use dry teflon lube.

Revision #3
Created 2025-06-02 15:29:27 UTC by Bookstack Admin
Updated 2026-04-25 19:07:15 UTC by Bookstack Admin