

# Downdraft Table Monthly Maintenance

Service manual: [https://drive.google.com/file/d/1t\\_Rllh8OS5fv1GuQ800Qa1ZzpGfTkGr9/view](https://drive.google.com/file/d/1t_Rllh8OS5fv1GuQ800Qa1ZzpGfTkGr9/view)

## \*Safety\*

- Wear a dust mask.
- Wear hearing protection.
- Wear safety glasses.

## \*Clean Downdraft Table\*

1. Clean and/or vacuum dust drawer. (Dust drawer located on front face, bottom, left hand corner.)
2. Remove table sections and vacuum exposed areas.
3. Open the motor door and vacuum the inside of cabinet.
4. Remove the filters and tap them out on the side of the dumpster - there's two of them (coarse and fine)

If suction is noticeably reduced, file a tool report (refer to "Servicing Filters" section of manual)

---

Revision #1

Created 2 June 2025 15:25:54 by Bookstack Admin

Updated 14 June 2025 15:10:55 by Bookstack Admin