

Jointer Maintenance - Weekly

Service manual: https://drive.google.com/file/d/1x37_ONdS5rXLuT0_jYOhp-QEAz2ClziH/view?usp=drive_link

Task List

1. Unplug the machine
2. Clean the cutter head.
3. Check cutter teeth for chips and dullness and file a tool report if needed - DO NOT ROTATE THE INSERTS
4. Generally inspect the machine for damage and loose or worn parts.
5. Check the dust extraction for blockages and any large bits that could cause blockages.

Revision #2

Created 2 June 2025 15:08:29 by Bookstack Admin

Updated 25 April 2026 18:53:46 by Bookstack Admin