

# Recharge 3D printer desiccant pack

## Recharge Desiccant Pack

1. Remove the white rectangular plastic desiccant pack from the "free filament" tote box by the 3D printing cabinet.
2. Inspect the desiccant beads through the front window.
3. Use the legend by the window to gauge if the beads are wet.
4. If the beads are wet, plug the desiccant pack into a wall outlet. \*Set a timer\* and check every two hours. The unit will heat up to drive out the moisture, which will bead up on the inside of the unit before evaporating. Once the condensation is gone and the beads are a happy color again, unplug the unit.
5. Return the dried desiccant pack to the filament box and ensure the lid is closed.

---

Revision #3

Created 2 June 2025 15:04:58 by Bookstack Admin

Updated 6 February 2026 17:53:59 by Bookstack Admin