

Test emergency lighting

Test Emergency Lighting

Turn off breaker 13 in panel A. (This breaker powers the emergency lighting.)

With the breaker off, confirm emergency lights are working in the following areas:

- by the bathrooms
- in the studio / front half of the building
- in the woodshop
- in the forge / loading bay

If any lights are not working, create a new tool report.

- Tool report: <https://airtable.com/appbIIORlmbIxNU1L/shrluff2WSzy8c3xd>

Revision #1

Created 2 June 2025 15:54:02 by Bookstack Admin

Updated 2 June 2025 15:54:32 by Bookstack Admin