

Throat Plate Printable Files

Replace the throat plate on the table saw with the printable in these files:

- [JetPlate v3.stl](#)
- [JetPlate v3.step](#)

Use either PETG or ABS filament to print the new throat plate.

Do not use PLA.

To install the printed throat plate, carefully move it into place with the saw running, using the blade to cut the clearance slot.

Revision #2

Created 26 January 2025 18:30:02 by Paul Mazaitis

Updated 22 March 2025 17:05:39 by Paul Mazaitis