

Deep Clean Tormach CNC

Safety

- Wear a dust mask. (If you do not have your own, disposable masks are available in the custodial room.)
- Wear safety glasses.
- Wear hearing protection.
- Wear gloves when handling chips.

Clean Tormach

1. Vacuum out the ways and the chip tray using the wet/dry vac next to the Tormach.
2. Remove any remaining visible chips from the front control panel, the coolant drain grate behind the machine, and elsewhere.
3. Clean off the keyboard, mouse, and monitor with a damp cloth.

Revision #1

Created 2 June 2025 15:53:26 by Bookstack Admin

Updated 2 June 2025 15:53:51 by Bookstack Admin